



1080P Full HDMI Autofocus Camera for Visual Inspection HDMI.27.2MAF

Description

HDMI.27.2MAF is a 1080P full HDMI Autofocus camera. It is a standalone camera and PC is not needed for operating this camera. With the help of autofocus system, refocusing while repositioning become very easy. Focus, brightness, sharpness and white balance can be controlled by the handy wired remote. This camera is an ideal tool for industrial inspection and soldering.

Features

- 1080p full HDMI resolution
- 60FPS high frame rate
- HDMI and SD card data output
- No PC or software required

Specification

Sensor	CMOS 1/2.8"
Resolution	1080p HD / 1920 x 1080 (24-bit, 16:9 Aspect Ratio)
Aspect Ratio	16:09
Frame rate	60fps
Interfaces	HDMI
Pixel	2 mega pixel (2.75x 2.75um)
Color	RGB (individual adjustment)
White balance	Auto/manual
Exposure	Auto/manual
Lens mount	C-Mount
Power	5-12VDC
Camera size	66x66x80 mm
Camera weight	420g
Operational Temperatures	0 - 50°C

Photos of this model are as following.

Address: 1805, Jingwei Plaza, No.58, Lane136, Shunde Rd. Haishu District, Ningbo, China

Tel:+86 574 87934732

Fax: +86 574 87934752

E-mail: sales8@ningbomicroscope.com **Skype:** colinxq

Microscope Web: www.ningbomicroscope.com

Teaching Instru web: www.hyoec.com



NINGBO HAISHU HONYU OPTO-ELECTRO CO.,LTD



Address: 1805, Jingwei Plaza, No.58, Lane136, Shunde Rd. Haishu District, Ningbo, China

Tel:+86 574 87934732

Fax: +86 574 87934752

E-mail: sales8@ningbomicroscope.com **Skype:** colinxq

Microscope Web: www.ningbomicroscope.com

Teaching Instru web: www.hyoec.com